



	Code	Description	Dimensions (cm)	Weight (kg)
1	50000	Non-Stick 27cm Medium Roaster	27 x 21.5 x 3.5 (Ext.)	0.218
2	50025	Non-Stick 35cm Large Roaster	35 x 26 x 4.5 (Ext.)	0.339
3	50050	Non-Stick 38cm XLarge Roaster	38 x 31.5 x 6 (Ext.)	0.479
4	50075	Non-Stick 22cm Quiche Tin	25 x 2.5 (Ext.)	0.205
5	50100	Non-Stick 36cm Oven Tray	36 x 25 x 2 (Ext.)	0.334
6	50125	Non-Stick Chip Tray	38.5 x 30.5 x 2 (Ext.)	0.387
7	50150	Non-Stick 30cm Pizza Tray	33 x 33 x 1.5 (Ext.)	0.291
8	50175	Non-Stick Baking Sheet	33.5 x 30.5 x 1.5 (Ext.)	0.539
9	50200	Non-Stick 12 Cup Muffin Tin	35 x 27 x 3.5 (Ext.)	0.518
10	50225	Non-Stick 12 Cup Bin Sheet	35.5 x 27 x 2.5 (Ext.)	0.355
11	50250	Non-Stick 22cm Springform	22.5 x 22.5 x 6 (Int.)	0.335
12	50275	Non-Stick 20cm Multi Use Tin	24 x 24 x 4 (Ext.)	0.264
13	50300	Non-Stick 18cm Sandwich Tin	19.5 x 19.5 x 3.5 (Int.)	0.163
14	50325	Non-Stick 2lb Loaf Tin	21.5 x 11 x 5.5 (Int.)	0.17
15	50350	Non-Stick 4 Cup Yorkshire Pudding Tray	23.5 x 23.5 x 2.5 (Ext.)	0.204



	Code	Description	Dimensions (cm)	Weight (kg)
16	50375	Non-Stick 20cm Round Cake Tin	20.5 x 20.5 x 8.5 (Int.)	0.336
17	50400	Non-Stick 20cm Square Cake Tin	20.5 x 20.5 x 7.5 (Int.)	0.42
18	50425	Non-Stick 21cm Sandwich Tin	22.5 x 22.5 x 5 (Int.)	0.232
19	50475	Non-Stick 18cm Springform Cake Tin	18 x 18 x 6.5 (Int.)	0.327
20	50500	Non-Stick 20cm Springform Cake Tin	20.5 x 20.5 x 6.5 (Int.)	0.385
21	50525	Non-Stick 24cm Springform Cake Tin	24.5 x 24.5 x 6.5 (Int.)	0.485
22	50550	Non-Stick Heart Springform Cake Tin	22.5 x 21.5 x 6.5 (Int.)	0.353
23	50575	Non-Stick Dual Oven Tray	40 x 35.5 x 2 (Ext.)	0.48
24	50600	Non-Stick Large Baking Sheet	41 x 35 x 1.5 (Ext.)	0.75
25	50625	Non-Stick 1lb Loaf Tin	19 x 9 x 5 (Int.)	0.142
26	50650	Non-Stick 24cm Pie Dish	23.5 x 3 (Ext.)	0.165
27	50675	Non-Stick 6 Cup Muffin Tin	26.5 x 18.5 x 3 (Ext.)	0.271
28	50700	Non-Stick Square Tray with Chevrons	31.5 x 31.5 x 2 (Ext.)	0.557
29	50725	Non-Stick 39cm Tray & Chevrons	39 x 31 x 1.5 (Ext.)	0.665



	Code	Description	Dimensions (cm)	Weight (kg)
30	50750	Non-Stick Deep Oven Tray	30.5 x 19 x 3.5 (Ext.)	0.257
31	50775	Non-Stick Large Multi Use Tray	36.5 x 24 x 5 (Ext.)	0.382
32	50800	Non-Stick 36cm Deep Roaster	36 x 28 x 6 (Ext.)	0.682
33	50825	Non-Stick 41cm Heavy Roaster	41 x 32 x 7 (Ext.)	0.872
34	50850	Non-Stick Trad 1lb Loaf Tin	15 x 9.5 x 7 (Int.)	0.202
35	50875	Non-Stick Trad 2lb Loaf Tin	18.5 x 11.5 x 8.5 (Int.)	0.278
36	51100	Non-Stick 30cm Deep Roaster	30.5 x 26 x 4.5 (Ext.)	0.507