



Code	Description	Dimensions (cm)	Weight (kg)
1	☉ 12370 Cuisine 800ml Rect. Food Box & Lid	19 x 14 x 5	0.085
2	☉ 12371 Cuisine 1.2L Rect. Food Box & Lid	19 x 14 x 8	0.0985
3	☉ 12372 Cuisine 1.6L Rect. Food Box & Lid	22.5 x 15.5 x 7.5	0.139
4	☉ 12373 Cuisine 2L Rect. Food Box & Lid	22.5 x 15.5 x 9.5	0.1535
5	☉ 12374 Cuisine 2.7L Rect. Food Box & Lid	26.5 x 18.5 x 8.5	0.215
6	☉ 12375 Cuisine 3.6L Rect. Food Box & Lid	26.5 x 18.5 x 11	0.2335
7	☉ 12376 Cuisine 4.5L Rect. Food Box & Lid	32 x 22.5 x 10	0.32
8	☉ 12377 Cuisine 6L Rect. Food Box & Lid	32 x 22.5 x 14	0.34
9	☉ 12383 Cuisine 1.2L Long Rect. Food Box & Lid	30 x 10 x 6.5	0.125
10	☉ 12202 Cuisine 10L Square Food Box & Lid	32.5 x 32.5 x 13	0.528
11	☉ 12203 Cuisine 15L Square Food Box & Lid	32.5 x 32.5 x 18.5	0.635
12	☉ 12379 Cuisine Set of 4 300ml Round Food Box & Lid	20 x 10 x 13	0.18
13	☉ 12395 Cuisine 2.5L Cereal Dispenser	24.5 x 9.5 x 26.5	0.252
14	☉ 12396 Cuisine 5L Cereal Dispenser	28.5 x 12.5 x 30.5	0.349
15	☉ 12388 Cuisine 2.4L Deep Rect. Food Box & Lid	19 x 14 x 16.5	0.17

☉ Clear ○ Ice White



	Code	Description	Dimensions (cm)	Weight (kg)
15	☉ 12389	Cuisine 3.2L Deep Rect. Food Box & Lid	22.5 x 15.5 x 16.5	0.229
16	☉ 12390	Cuisine 3.9L Deep Square Food Box & Lid	20 x 20 x 16.5	0.208
17	☉ 12393	Cuisine 1.8L Square Food Box & Lid	20 x 20 x 7.5	0.1525
18	☉ 12394	Cuisine 2L Square Food Box & Lid	23 x 16 x 9.5	0.161
19	○ 12387	Cuisine 20cm Handled Colander/Sieve	32 x 20 x 9	0.118
20	○ 12386	Cuisine 30cm Colander	30 x 30 x 12.5	0.216
21	☉ 12292	Cuisine 25cm Microwave Cover	25 x 25 x 9.5	0.145
22	☉ 12293	Cuisine 30cm Microwave Cover	30 x 30 x 9.5	0.196
23	☉ 12180	Cuisine 2L Mixing Bowl	24 x 22.5 x 13	0.128
24	☉ 12181	Cuisine 4L Mixing Bowl	30 x 28 x 16	0.1955
25	☉ 12182	Cusine 7L Mixing Bowl	34 x 33 x 19	0.322
26	☉ 32000	Cuisine 1L Measuring Jug	20 x 12.5 x 14.5	0.109
27	☉ 12291	Cuisine 2L Measuring Jug	12.5 x 20 x 21.5	0.166
28	☉ 16445	350ml Screw Top Beaker	7.50 x 7.50 x 13	0.063

☉ Clear ○ Ice White